

USER MANUAL

PureKeys Compact Keyboard

Model: PK-KBC-01001

This keyboard is plug and play compatible with Windows PC's, no additional drivers needed. After plugging in the keyboard in a free USB port it may take a few minutes for the drivers to install.

The elastomer cover can be cleaned with hospital grade disinfectants including alcohol 80%. Before starting the cleaning process press the CLEAN button until the light goes on. After placing the keyboard in cleaning mode it can be cleaned and the activation of any key does not result in unwanted input. After pressing the CLEAN button again the keyboard will become active and ready for use.

On the bottom you can place 4 x 5mm rubber feet or 2 x 5mm in the front and 2 x 15mm in the rear depending on the required angle

Purekeys declares that this product is in accordance with essential requirements and other relevant terms of the European regulation 2004/108/EC.

Doc. 9 ver.1.23

USER MANUAL

PureKeys Compact Keyboard

Model: PK-KBC-01001

This keyboard is plug and play compatible with Windows PC's, no additional drivers needed. After plugging in the keyboard in a free USB port it may take a few minutes for the drivers to install.

The elastomer cover can be cleaned with hospital grade disinfectants including alcohol 80%. Before starting the cleaning process press the CLEAN button until the light goes on. After placing the keyboard in cleaning mode it can be cleaned and the activation of any key does not result in unwanted input. After pressing the CLEAN button again the keyboard will become active and ready for use.

On the bottom you can place 4 x 5mm rubber feet or 2 x 5mm in the front and 2 x 15mm in the rear depending on the required angle

Purekeys declares that this product is in accordance with essential requirements and other relevant terms of the European regulation 2004/108/EC.

Doc. 9 ver.1.23