

Features & Benefits

Patented Touch-Tap™ Technology

Cleankeys is the only touch keyboard that allows you to rest your fingers while typing; plus Cleankeys resolves the conflict that arises when a finger lands between two keys, choosing the most likely letter based on the word you are typing. These features make the keyboard very accurate.

CleanSweep™ Monitoring Software

CK3-15 is amongst the new line of our keyboards to have revolutionary new self-monitoring software that will let you know when to clean, and also how well the keyboard has been cleaned.

Corning® Gorilla® Glass

Gorilla Glass (GG) means that the keyboard is thinner, lighter, resistant to scratching & harsh cleaning chemicals, & stronger than standard glass.

Fully Certified

ISO layout means all the keys you'd expect on a full-sized keyboard. FCC, CE, RCM, IP65 certifications mean its safe and reliable.

In-place Cleaning

Just pause, spray, and wipe. No need to unplug and take it to a sink.

Touchpad / Numeric Keypad

Data entry and cursor control made easier by a combined touchpad- / numpad area.

Wireless

CK3-15 uses a small USB receiver that plugs into the computer, that in turn receives a signal from keyboard. This "frequency agile" radio means no interference with other wireless devices.

Audible Feedback

Instant confirmation when a key is typed.

Volume Control

Six volume levels including OFF allows you to tailor the audible feedback to your environment.

Works with Gloves

A five point sensitivity setting means that big fingers, little fingers, and gloves are no problem; all can be accommodated by changing the sensitivity setting.

Plug-and-Play using Standard USB

There is no special software required on your computer to use Cleankeys - just plug and play.

Multi-Platform

Mac, Windows, Linux, & Unix.

Ergonomic

Built-in tilt, full-sized keys, and non-skid rubber feet help make the user experience a comfortable delight.

Control Panel Software

Easy access to keyboard settings.

Technical Specifications

Keyboard

Length: 15.24 in. (387 mm)
Width: 5.91 in. (150 mm)
Height: 0.87 in. (22 mm)
Weight: 1.47 lbs (0,67 kg)

Wireless Receiver Size

Length: 1.89 in. (48 mm)
Width: 0.67 in. (17 mm)
Weight: 0.21 oz (6 g)

Material

Base: Polycarbonate (PC), white
Top: Corning® Gorilla® Glass 2

Power Specifications

AC input: 100-240V, 1A, 0-60Hz
DC output: 5V, 1A (charging)
USB input: 5V, 150mA nominal
Wireless Receiver Power: 5V @ 22mA

Connectivity

USB Cable: 6.8 ft. (2.0 m)
Wireless Interface: 2.4 GHz
Wireless Range: 30 ft. (10 m)

Operating Temperature

5°C to 32°C (41°F to 90°F)

Water and Dust Ingress

IP65 Rated

Supported OS

WinXP or higher, Mac OSX, Linux, Unix

Warranty

Two years

Regulatory Compliance

Complies with FCC Part 15, Sub part B.
RoHS compliance adhered to for the European Directive.

RCM compliance adhered to for Australia/
New Zealand. (C-Tick Mark)

Canada

EMC: ICES-003
Radio (intentional transmitter): RSS210

United States

EMC: FCC Part 15 Subpart B
Radio: FCC 15.247

European Union (EU)

EMC: EN 55022, EN 55024, EN 61000-3-2,
EN 61000-3-3,
Radio: EN 300-440-1, EN 301-489-1

Australia/New Zealand

EMC: AS/NZS 3548, Radio: AS/NZS4771
Safety: AS/NZS 60950-1

Safety

EN 60950-1